Model FL8300

5 Disc Compact Disc Changer

SERVICE MANUAL



CONTENTS

LASER BEAM SAFETY PRECAUTIONS	32	TECH TIP TIP# HKTT2003-02	26
OTHER PRECAUTIONS	3	TROUBLESHOOTING	27
LEAKAGE TEST	4	PRINTED CIRCUIT BOARDS	34
SPECIFICATIONS	5	GENERAL UNIT EXPLODED VIEW I, II	37
CONTROL AND FUNCTIONS	7	GENERAL UNIT PARTS LIST	40
BLOCK DIAGRAM	9	ELECTRICAL PARTS LIST	41
PICKUP REPLACEMENT	11	SEMICONDUCTOR IDENTIFICATION	44
CIRCUIT DESCRIPTION	13	PACKAGE	52
BULLETIN #9604	22	SCHEMATIC DIAGRAM	53
BULLETIN #9607	23	WIRING DIAGRAM	61
RI II I ETINI #0703	24		

harman/kardon, Inc. 250 Crossways Park Dr. Woodbury, New York 11797

LASER BEAM SAFETY PRECAUTIONS


CLASS 1 LASER PRODUCT

CLASS 1 LASER PRODUCT

CAUTION


Invisible laser radiation when the unit is open. DO not stare into beam.

CAUTION: USE OF ANY CONTROLS, ADJUSTMENT, OR PROCEDURES OTHER THAN THOSE SPECIFIED HEREIN MAY RESULT IN HAZARDOUS RADIATION EXPOSURE.



Do not look directly at the laser beam coming from the pickup or allow it to strike against your skin.

This compact disc player uses a pickup that emits a laser beam. The laser beam is emitted from the location shown in the figure. When checking the laser diode, be sure to keep your eyes at least 1 foot away from the pickup lens when the diode is turned on. Do not look directly at the laser beam.



CAUTION:

Using controls and adjustment, or doing procedures other than those specified herein, may result in hazardous radiation exposure.

SAFETY PRECAUTIONS



CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



This symbol is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

Caution: To prevent electric shock do not use this (polarized) plug with an extension cord, receptacle or other outlet unless the blades can be

fully inserted to prevent blade exposure.

Attention: Pour prévenir les chocs électriques ne pas utiliser cetre fiche polarisée avec un prolongateur, une prise de courant ou une autre sortie de courant, sauf si les lames prévent être insérées à fond sans en laisser aucune partie à découvert.

WARNING

To prevent fire or shock hazard, do not expose the unit to rain or moisture.

HANDLING LASER PICKUP

The laser diode in the optical system of this player can be damaged by electrostatic discharge from your clothes or your body. Proper electrostatic grounding for service personal is required during servicing.

BEFORE REPAIRING THE COMPACT DISC PLAYER

Preparation

Human Body Grounding:

Many of the components used in this compact disc player, including the laser pickup, are sensitive to electrostatic discharge. Service personal should be grounded with an electrostatic armband (1 Mohm).

· Caution:

Static charge on clothing does not escape through a body grounding wrist band. Be careful not to contact the pickup or electrical components with your clothing.

Workbench and Tool Grounding:

A properly-grounded electroconductive plate (1 Mohm) or metal sheet should be fitted to the workbench surface. Tools and instruments (such as soldering irons and scopes) should be grounded to prevent AC leakage.



Incorrect

Fig. 1




Fig. 2

Note: Laser diodes are so susceptible to damage from static electricity that, even if a static discharge does not ruin a diode, it can shorten its life or cause it to work improperly.


LEAKAGE TEST

Before returning the unit to the user, perform the following safety checks:

- Inspect all lead dress to makes certain that leads are not pinched or that hardware is not lodged between the chassis and other metallic parts in the unit.
- Be sure that any protective devices such as nonmetallic control knobs, insulating fishpapers, cabinet backs, adjustment and compartment covers or shields, isolation resistor-capacity networks, mechanical insulators, etc. Which were removed for servicing are properly reinstalled.
- Be sure that no shock hazard exists; check for leakage current using Simpson Model 229 Leakage Tester, standard equipment item no. 21641, RCA model WT540A or use alternate method as follows: plug the power cord directly into a 120-volt AC receptacle (do not use an Isolation transformer for this test).

Using two clip leads, connects a 1500 ohm, 10-watt resistor paralleled by a 0.15µF capacitor, in series with all exposed metal cabinet parts and a known earth ground, such as a water pipe or conduit. Use a VTVM or VOM with 1000 ohms per volt, or higher sensitivity to measure the AC voltage drop across the resistor. (see diagram) Move the resistor connection to each exposed metal part having a return path to the chassis (antenna, metal cabinet, screw heads, knobs and control shafts, escutcheon, etc.) and measure the AC voltage drop across the resistor. (This test should be performed with the power switch in both the on and off positions.)

A reading of 0.35 volt RMS or more is excessive and indicates a potential shock hazard which must be corrected before returning the unit to the owner.



SPECIFICATIONS

General

Transmission bit rate

Transmission on clock

Error correction

4.3218 Mbit/sec

16:9344 MHz

CIRC C1, C2 Double correction

Pickup

System

Object lens drive system

Optical source

Wave length

Tracking system

Object lens drive type optical pickup

2 Dimensional parallel drive type

Semiconductor laser

760-800 nm

3 Beam tracking servo type

Others

D/A converter

Power requirements

Power consumption

Dimensions (HxWxD)

Weight

1 bit (Bitstream Conversion)

USA and Canada Version: 120 V AC, 60 Hz

Europe Version: 230 V AC, 50 Hz

12 W

95 × 440 × 300 mm

6.08 kg

Electrical

* Preparations

· measuring methods in confirmity with EIAJ CP-307, CCIR 468-3.

· Reference level: 0 dB(LINE OUT 2 V).

· Test disc: SONY CD3 YEDS 7, A.BEX TCD 725.

Description	Signal	Track	Unit	Norminal	Limit	Test Disc
Frequancy Response	20~20000 Hz	2~13	dB	<u>+</u> 0.5	+1	
Signal to Noise Ratio (Weighted JIS A)	1 kHz	23	dB	>95	>90	SONY
Dynamic Range (Weighted JIS A)	1 kHz, 60 dB	20	. dB	>90	>85	CD3
Total Harmonic Distortion at 0 dB	100 Hz	4	%	≤0.08	≤0.1	YEDS 7
(Filter 30 kHz)	1 kHz	7	%	≤0.04	≤0.05	
	20 kHz	13	%	≤0.1	≤0.15	
	100 Hz	29, 33	dB	≥82	≥80	
Channel Separation	1 kHz	30, 34	₫B	≥82	≥80	
(Filter 30 kHz)	10 kHz	31, 35	dΒ	≥80	≥78	
	20 kHz	32, 36	đВ	≥76	≥73	
Channel Unbalance	1 kHz	7	₫B	+0.2	+0.5	
Output Voltage	1 kHz	7	V	2 ± 0.3	2±0.5	
	1 kHz	39	d₿	-0.37 ± 0.2	-0.37 + 0.3	
De-emphasis	5 년12	40	dB	-4.53 ± 0.3	-4.53 ± 0.5	
	16 kHz	41	dB	-9.04 ± 0.5	-9.04 ± 1.0	
Disc Defecte Back Dot		10~15	μm	≥700	≥600	
/ Inetrrupt		3~9	μm	≥800	≥700	A.BEX
Fingerprint		17~19	μm	ALL	ALL	TCD 725

Environmetal

Test to specification

Temperature between 59°F (15°C) and 95°F (35°C) and relative humidity between 45% and 75%, with power supply voltage of 10% the normal supply voltage.

Operation


Unit must work properly and correctly at the temparature range from $32^{\circ}F$ (0°C) to $113^{\circ}F$ (45°C) and the relative humidity from 40% to 80%, and with the supply voltage.

Storage

Temperature test: 48 hours each at -40°F (-40°C) and 149°F (65°C).

Humidity test: 40°C, 95% relative humidity.

CONTROL AND FUNCTIONS



1. POWER SWITCH

Press the POWER switch to turn this unit on and press it again to turn it off. For system operation, plug the AC input cord into the switched AC outlet, keep the power switch ON and control power ON/OFF with the main POWER switch on the amplifier or receiver.

2. MULTI-FUNCTION DISPLAY

This display shows the corresponding information according to each mode.

3. DISC TRAYS (1 - 5)

One disc per tray can be loaded with the labelled side up.

4. PLAY/PAUSE BUTTON (►II)

This button is used for starting play, pausing play at the beginning of a track or interrupting play.

5. STOP/CLEAR BUTTON (=)

This button is used for stopping play, clearing programmed selections or recovering the deleted selections.

6. BACKWARD SKIP/ SEARCH BUTTON (◄◄)

This button is used for replaying from the beginning of the current track, returning to a previous track or searching for a particular passage in fast reverse.

7. FORWARD SKIP/ S BUTTON (►►I)


This button is used for movi the next track or searching! particular passage in fast fo

8. REPEAT BUTTON

This button is used for repertrack, one disc or all discs.

9. RANDOM PLAY BU

This button is used to let the automatically select and pla randomly on each CD or rar between discs and tracks.



FORWARD SKIP/ SEARCH ITTON (►►)

s button is used for moving on to next track or searching for a ticular passage in fast forward.

REPEAT BUTTON

s button is used for repeating one ik, one disc or all discs.

RANDOM PLAY BUTTON

s button is used to let the unit omatically select and play tracks domly on each CD or randomly ween discs and tracks.

10. TIME BUTTON

This button is used for checking the elapsed playing time from the beginning of the current track, remaining playing time of the current track or remaining playing time of the disc.

11. DELETE BUTTON

This button is used for deleting the undesired tracks or discs.

12. DISC SELECTOR BUTTONS

These buttons are used for selecting the disc to be played.

13. DISC SKIP BUTTON

Each time this button is pressed to load or unload the disc, the carousel will rotate to the next tray position clockwise.

14. INFRARED RECEIVER WINDOW

This receives the infrared signals transmitted by the remote control and converts it into the electrical signal to control this unit.

15. TAPE SIZE BUTTON

This button is used for selecting the tape length.

16. EDIT BUTTON

This button is used for editing the tracks to be recorded onto the cassette tape.

17. DISC INTRO BUTTON

This button is used for playing the first 10 seconds of each track or the first track on CDs.

18. OPEN/CLOSE BUTTON

This button is used for opening and closing the tray.


19. PROGRAM/REVIEW BUTTON


This button is used for programming your favorite tracks or discs or reviewing the programmed selections.

20. HEADPHONE JACK

This is used for listening with headphones.

BLOCK DIAGRAM





PICKUP REPLACEMENT

Caution:

Laser diodes are extremely susceptible to damage from static electricity. Even if a static discharge does not ruin the diode, it can shorten its life or cause it to work improperly. When replacing the pickup, take appropriate measures, such as using a conductive mat and a grounded soldering iron, to protect the laser diode from static damage.

1. Remove the CD mechanism assembly by refering to the "EXPLODED VIEW II" on page 31 (See Fig. 3).





Fig. 3

2. Remove four screws S12 (See Fig. 4).



- 3. Remove the gear A (See Fig. 5).
- 4. Pull out the slide shaft.




Fig. 5

5. Remove the pickup (See Fig. 6).




Fig. 6

6. After you connect the wire connector, desolder and remove the shorting tab (See Fig.7).




Fig. 7

7. Refer to the "EXPLODED VIEW II" of the compact disc mechanism on page 31 for detailed illustrations.

OPERATION CHECK


When the power switch is turned on after the chucking arm is removed, observe the objective lens and check the following. (The optical system block should be at the lead-in position when it is checked.)

- 1. The disc table should be at the innermost position after the chucking arm is removed.
- 2. The diffused light of the laser beam can be seen when the power switch is turned on.
- 3. Vertical (up and down) movement of the objective lens take place (2 or 3 times).

CIRCUIT DESCRIPTION

1. CPU(IC112 : CXP82320-322) EXPLANATION

1-1. Pin Description & Block Diagram



1-2. Pin Functions

Pin No.	Symbol	Description		
1	ONE MODE	Test mode for production.		
2	REMOCON	Input for remocon data.		
3 - 5	NC	Not used ! (It should be left to open.)		
6	CNIN	Signal input for automatic tracking adjustment from CXD2507.		
7	NC	Not used ! (It should be left to open.)		
8	A-MUTE	Output for audio mute.		
9	G-MUTE	Not used ! (It should be left to open.)		
10	XLT-0	Serial latch data output to CXD2507.		
11	SQCK	Clock data output for subcode-Q readout to CXD2507.		
12	SUBQ	Subcode-Q data input from CXD2507.		
13	DATA	Serial data output to CXD2507.		
14 - 17	KEY INPUT	Data input for key scan.		
18 - 19	GND	Ground.		
20	FOK	FOK data from CXA1782BQ.		
21	GFS	GFS data from CXA1782BQ.		
22	SENSOR-R	Roulette sensor data input from mecha.		
23	SENSOR-D	Disc sensor data input from mecha.		
24	NC	Not used ! (It should be left open.)		
25	XRST	Output fot resetting CXD2507.		
26 - 27	NC	Not used ! (It should be left open.)		
28	RSTN	Output for resetting SM5871AS.		
29	NC	Not used! (It should be left open.)		
30	RST	Input for resetting CPU.		
31	EXTAL	Input of 10 MHz oscillator crystal.		
32	XTAL	output of 10 MHz oscillator crystal.		
33	VSS	Ground		
34	CLOSE-LD	Output for driving motor to close the tray.		
35	OPEN-LD	Output for driving motor to open the tray.		
36	NC	Not used! (It should be left open.)		
37	RIGHT	Output for roulette motor to rotate the disc platter right.		
38	LEFT	Output for roulette motor to rotate the disc platter left.		
39	NC	Not used ! (It should be left open.)		
40	UP	Output for chucking motor.		
41	DOWN	Output for chucking motor.		
42 - 57	SEGMENT	Segment signal output.		
58 - 62	NC	Not used! (It should be left open.)		
63 - 70	GRID	Grid signal output.		
71	VFDP	-35 V power supply for F1 controller.		
72	VDD	+5 V power supply for CPU.		
73~77	NC	Not used ! (It should be left open.)		
78	PD	Input signal for power down.		
79	SENS	Sens signal input from CXD2507.		
80	SCOR	Subcode-Q readout timing input from CXD2507.		

2. APC CIRCUIT

A semiconductor laser is used as the light source for the optical pickup. As the laser diode has large negative temperature characteristics in its optical output when driven with a constant current, a circuit must be provided to stabilize this output. For this purpose, a monitor diode which detects the optical output of the laser diode is used in the semiconductor laser.

As the laser diode emits light from its bonded surface, light is emitted both in front and behind. The light emitted behind is monitored with the monitor diode installed on its rear surface, and the optical output is thus controlled. The light emitted in front becomes the light source for the pickup.

Fig. 8 shows the APC circuit.

When the temperature rises and the optical output decreases, the monitor diode current (Is) decreases, the electric potential of IC113 pin 33 rises, the base current of the driving transistor increases, and the laser diode current increases. This causes the reduced optical output to return to its former level.




Fig. 8

3. FOCUS SERVO

3-1. Optical pickup (Fig. 9)

This set employs a three-beam optical pickup comprised of six division photodiodes, A through F as shown in Fig. 9. The four photodiodes (A through D) at the center provide focus error detection by using their property to allow the beam to focus into a round image only at a certain point.

The sums of outputs from diagonal two elements of four division photodiodes (A+C and B+D) are compared by the differential amplifier in IC113 to detect the shape of the beam image.

The remaining two diodes (E and F) provide tracking error detection by means of sub-beam spots.





Fig. 9

3-2. Focus error detecting operation (Fig. 10)

The reflected laser beam from a disc is polarized 90° with the beam-splitter and sent to the cylindrical lens. The beam passed through this cylindrical lens is then sent to the four division photodiodes and focuses into an image whose shape varies with the distance between the disc and the objective lens. Such change in the beam shape causes the current flowing from the photodiodes to vary.

Shown in Fig. 10 is the principle of the focus error detection.

The currents from the photodiodes (A+C and B+D) are applied to pins 35 and 36 of IC113 and converted to voltage by RF I-V amplifiers (1) and (2) included in IC113.




3-3. Focus servo control operation (Fig. 11)

The focus error signal, after being converted to voltage by the RF I-V amplifier, is transmitted to the operation amplifier in the IC113 and output from pin 1.

When the disc to objective lens distance is in focus, the beam forms a true round. In this state, the beams applied to four elements of four division photodiodes become equal and thus the output provided then is 0(zero). When the disc to objective lens distance is too close (near focus), the beam is reflected divergently to form an oval in crosswise direction. In this state, the outputs provided from photodiodes A and C are higher than those from B and D, resulting in negative (–) output voltage. On the other hand, when the distance is too far (far focus), the beam is reflected convergently to form an oval in longitudinal direction. Then the outputs from photodiodes B and D are higher, resulting in positive (+) output.

The focus error amplifier calculates the difference between output VA and VB of the RF I-V amplifier, and output current-voltage converted voltage of the photo diode (A+C-B-D). Fig. 11



The FE output voltage (low frequency) is VFE=5.4 \times (VA-VB)=(iPD2-iPD1) \times 315 k Ω . Be aware that the rotation of the focus bias volume has reversed for the usual CD RF IC.

3-4. Tracking error detection system (Fig. 12)

Fig. 12 shows the principle of the tracking error detection system which employs the three beam system.

The laser beam is divided into the main beam and two sub-beams by diffraction grating and they are arranged on one line. The center line connecting these three beams has a slight offset angle against the main beam. The main beam is received by photodiodes A, B, C and D and two sub-beams by E and F respectively.

Fig. 12-A shows the on-track state. As both auxiliary beams 1 and 2 are slightly on the track in this state, the outputs of photodiodes E and F are equal and the tracking signal is 0(zero). When the track is shifted to the left (Fig. 12-B), the auxiliary beam 1 is off the pit. This allows more light to be received by the photodiode E, resulting in positive (+) tracking signal output. On the other hand, when the track is shifted to the right (Fig. 12-C), the amount of light received by the photodiode F increases, resulting in negative (-) tracking signal output. And these extreme signals are detected as tracking error signals.




Fig. 12

3-5. Tracking servo control operation (Fig. 13)

The photo diode currents input at E and F pins are each current-voltage converted by the E I-V and FI-V amplifiers.




Fig. 13

IC113 tracking block has built-in circuits for balance and gain adjustments to enable software based automatic adjustment.

The balance adjustment is performed by varying the combined resistance value of the T-configured feedback resistance at E I-V AMP.

- F I-V AMP feedback resistance = RF1+RF2+(RF1 \times RF2)/RF3=403 k Ω
- E I-V AMP feedback resistance = Re1+Re2+(Re1 × Re2)/Re3.

Vary the value of RE3 in the formula above by using the balance adjustment switches (BAL 1 to BAL 3). For the gain adjustment, resistance divide the TE AMP output with the gain adjustment switches (GOG 1 to TOG 3), and output at Pin 42.

These balance and gain adjustment switches are controlled through software commands.

3-6. Tracking automatic adjustment for gain/balance (Fig. 14)




Fig. 14

IC113 has Balance control, Gain control, and comparator circuit required to perform tracking automatic adjustment. LPF is set externally at approximately 100 Hz.

4. Regenerative Circuit

4-1. RF circuit (Fig. 15)

The currents from photodiodes (A, B, C and D) are fed to IC113 through pins 35 and 36 and converted to voltage by RF I-V amplifiers (1) and (2) respectively there, added by the RF summing amplifier and output from pin 31 as a signal. It can be checked at the test point (RF T.P.) provided on its way by means of the eye pattern check.





Fig. 15

4-2. Digital Signal Processor (Fig. 16)


The EFM signals from pin 31 of IC113 are sent to pin 14 of IC107, then demodulated from 14 bits to 8 bits by EFM readjustment. At the same time any error, if found, is corrected (CIRC) and the signals are sent to the D/A converter interface. After that they are output as 16-bit digital signals from pins 20, 21 and 22 of IC104. In this case, EFM demodulation, error correction and serial/parallel conversion are performed by the internal circuitry of IC107.



5. Audio Circuit

5-1. Configuration of SM5871AS

Fig. 17 shows the configuration of the SM5871AS.



IC104 is a highspeed converter for digital audio systems fabricated using NPC's molybdenum-gate CMOS process. It incorporates a two-channel, 16-bit D/A converter and a four-times digital oversampling filter.

IC104 can operate at three different sampling frequencies and incorporates deemphasis, attenuation and soft mute functions.

Double-speed dubbing is supported without any change in clock frequency.

IC104 linearly interpolates the input signal at a high multiple of the original sampling frequency, and then requantizes the resulting signal. A third-order noise shaper is used to remove most of the quantizing noise before the signal is output as a pulsewidth-modulated (PWM) waveform.

5-2. Audio Circuit

Fig. 18 shows a block diagram of the audio circuit.

The output from pin18(LO) (INTC+) and pin20(LON) (INTL-) of the IC104 D/A Converter SM5871AS is input to the differential input amplifier, which is symmetrical in the up and down directions, of the discrete circuit configured of the following stage, which includes Q113, Q115, Q123, Q127, Q117, Q119, Q121, and Q125. The output undergoes differential synthesis in this ciruit, and after synchronous-phase noise has been eliminated, the resulting signal is output to the low-pass filter of the discrete circuit configuration of the following stage as an audio signal.





Fig. 18



Service Bulletin

Service bulletin # 9604 rev1 - October 1998

This is considered a Minor Repair

To: All harman/kardon Service Centers

Models: FL8300

Subject: Digital Output Level

The Digital Interface Standard recommends D/A converters have a minimum Input sensitivity of 200 mV. In early FL8300 production units, the Digital Output level was 240 mV $\pm 10\%$ peak to peak. Based on our research, we found that some D/A converters require more than 240 mV for intermittent free operation.

In the event you receive a FL8300 from a consumer with the a complaint "Intermittent Sound from External D/A converter", check the serial number in the table below.

If the FL8300 has a serial number *higher* than indicated in the table below, connect a properly working D/A converter to the Digital Output and verify interruption free operation. Also confirm the Digital Output level of the FL8300 is 500 mV $\pm 10\%$ Peak to Peak. If the FL8300 passes these two tests, advise the customer to have their external D/A converter and connecting cables checked.

If the FL8300 has a serial number *lower* than indicated in the table below, perform the following modification:

- 1) With the unit plugged in and turned on, push the "open/close" button to extend the drawer fully; then turn the unit off and unplug it.
- 2) Open the top cover (6 screws).
- 3) Remove output board PCB3 from the rear panel (4 screws). This board can be pulled back and modified without completely removing it from the chassis.
- 4) Locate resistor R901, it may be a 680 ohm resistor or a jumper wire; replace in either case with a 0.47 uf capacitor h/k part# 5354-474593.
- 5) Locate R903 and change from 680Ω to a $4.7k\Omega$ resistor h/k part # 3029472970. Re-attach output PCB3 to the unit.
- 6) Connect a 75 Ohms cable to the digital output jack. Terminate this cable with a 75 Ohm load; connect an oscilloscope to the 75 Ohm termination resistor. While playing a CD, confirm the output of the signal is now 500 mV ±10% peak to peak.
- 7) Reassemble the FL8300 and test all functions.

Model	Serial number 120V	Serial number 230V	Status	Action
FL8300	IN0019-01001 to IN0019-19393	IN0020-01001 to IN0020-04500	May have low digital output for some applications	Replace R901 with 0.47 uf mylar capacitor h/k part# 5354-474593 Replace R903 with 4.7k ohm resistor h/k part# 3029472970
FL8300	IN0019-19394	IN0020-04501	Factory Installed *	NONE REQUIRED

^{*} Factory modification of the FL8300 starting with the serial numbers indicated in the above table consisted of:

R236: 1k Ohm

R901: Jumper or 680 Ohm

R903: Changed from 680 Ohm to 4.7k Ohm.

Digital output level into 75 Ohms: 500 mV ±10% peak to peak.

Service Bulletin

Service bulletin # 9607-January 97

This is considered a Major Repair

To: All harman/kardon Service Centers

Models: FL8300 Compact disc changer

Subject: Failure to play Multi-media CDs or skip data tracks

Early FL8300 CD Players used a micro-computer which could not read the table of contents (TOC) of certain multimedia CD's or skip data tracks on multimedia CD's. During two running production changes, new Microprocessor were installed which performs as shown in the table below:

Description IC112	Part Number	Serial number Range120V	Serial number Range230V	Processor action	Year/Month first used
CXP21320-322	2138322197	IN0019-01001 to	IN0020-01001 to	Does not play Multimedia CD	95 October
DWP325		IN0019-29000	IN0020-05500		
CXP82320-352Q	2139322710	IN0019-29001 to	IN0020-05501 to	Plays Multimedia CD,	96 July
DWP325A		IN0019-53790	IN0020-08510	Mutes at data track	
CXP82320-367Q	2139322722	IN0019-53791 to	IN0020-08511 to	Plays Multimedia CD, Skips	96 November
DWP325B		present production	present production	data tracks	

In the event you receive a FL8300 from a consumer with a complaint "Player will not read or, loudspeakers make strange noise while playing multimedia CDs", replace IC112 with H/K Part number 2139322722.

The IC can be identified by CXP82320-367Q DPW 325B printed on its case.

Service Bulletin

Service bulletin # 9703 June 1997

This is considered a Major Repair

To: All harman/kardon Service Centers

Models: FL8300

Subject: Dead unit, no display; Service upgrade

In the event you receive an FL8300 that is dead, and upon inspection R701 is damaged or an otherwise open circuit, perform the necessary steps listed below:

Due to current surges, early models of the FL8300 could repeatedly damage R701 (either a 1 ohm resistor or 1.5A micro fuse depending on version). Along with the replacement of R701, the positive lead should be relocated on C125 to suppress any future current surges.


Additionally, two capacitors, now designated as C907 & C908, (1uf/50v) should be added to the power supply output pins on regulator IC108 & IC111 on a unit serviced for any reason; these will add stability to help prevent oscillation.


PROCEDURE:

- 1) Replace R701 with micro-fuse H/K # 5508722221, this component is on PCB7.
- 2) A PCB trace should be cut on the C125 (2200 uf/25v) positive lead on the main circuit board and an insulated jumper wire attached from that lead to the junction of D109/110. Additionally another insulated jumper will need to replace the trace that was cut. (see drawing)
- 3) Add C907 & 908, 1uf/50v, H/K/ # 3479310971, one on each output pin to ground on regulators IC108 and IC111. This is most easily accomplished by:
 - Soldering one 1uf cap to the jumpers 153 & 197. Observe polarity; J153 is ground.
 - Soldering one 1uf cap to the jumpers 185 & 186. Observe polarity; J186 is ground.

Model	Serial number	Serial number	Action	Correction
	120V	230V		
FL8300	IN0019-72213	NOT REQUIRED	R701 is damaged or	Replace R701,
	and below		an open circuit	re-route positive connection on C125,
				Add C907/908
FL8300	IN0019-72214 and above	NOT REQUIRED	Modified by factory	NONE REQUIRED

PCB1 (MAIN) BOTTOM VIEW





TECH TIPS

Troubleshooting tips and solutions to common service problems


For models: FL8300 TIP# HKTT2003-02

Problem: "Carousel not stopping in the correct position, so disc can be clamped correctly".


Check:

- 1) 6-conductor Ribbon cable connection to sensor board check cable; clean, re-seat at both ends.
- 2) There is a post/standoff underneath the single center screw in the center of the carousel (under the plastic 1,2,3,4,5 cap). If that post/standoff is too long, it can cause the symptom. If the part is higher than the surface of the carousel in that area, the part needs to be shaved down so it's shorter.
- 3) Defective Roulette sensor (part# 2408001111) or Disc sensor (part# 2408210001).


TROUBLESHOOTING




[Repair item 1] At power on, "No disc" and some parts are not displayed.




[Repair item 2] Tray cannot opened and closed by pressing "OPEN/CLOSE" button.




[Repair item 3] " \mathcal{S} " is displayed instead of total playing time and track number.




[Repair item 3-A] Sled motor does not move.




[Repair item 3-B] Laser does not emit.





[Repair item 3-C] Object lens of pickup unit does not move up and down.






[Repair item 3-D] Spindle motor does not rotate.






PRINTED CIRCUIT BOARDS


PCB2(POWER)




PCB7(POWER S/W)



PCB9(CONNECTION)





PCB5(RMC SENSOR)




4005512500B FRONT B'D


PCB8(LED)









GENERAL UNIT EXPLODED VIEW I





GENERAL UNIT EXPLODED VIEW II



GENERAL UNIT PARTS LIST

Ref. No.	Description	Mfr. Part No.	Q'tv
	CABINET & CHASSIS		
1 2	Panel, Front, ABS, Black Door, Tray, ABS, Black	048501036211 048562006511	1
3	Button, Power	048545130811	ì
4	Light Shield	8535046020	1
5 6	Indicator, Power Spring, Button	8555052110 6555010720	1
7	Button Function, 3key	048543068811	1
8 9	Window, Display	8553022810 048553022911	1
10	Filter, FL Button Function, 8key	048543068911	i
11	Button, Open/Close	048545130611	1
12 13	Bracket, Phone Chassis, Main	6505110210 6121614510	1
14	Foot PL(H.S)	046033102511	1
15 16	Foot PL(H.S) Foot Base	046033102511 046035101511	1
17	Foot Base	046035101511	i
18	Cover Chassis Fuse	6123017710	1
19 20	Holder, FL Heatsink Regulator TR.	6513004420 7505202410	1
21	Heatsink Regulator TR.	7505202410	1
22 23	Heatsink Regulator TR. Jack RCA, 1P	7505206110 4438111020	1
24	Jack, Multi, 2P	4438007510	1
25 26	Jack RCA, 2P	4438111320 046102044021	1
27 <u>/</u> 1	Chassis, Back Cord, AC Power	4308001410	i
28	Holder, Power Cord	6518002310	1
29 30	Cover, Top Cover Roulette	6122022030 048583005911	1
SW701 SW101	Switch, Push, Power Switch, Tact	4628058310 4658003710	1
SW401-413	Switch, Tact	4658003710	13
SW501-506	Switch, Tact	4658003710	6
JACK601	Jack, Phone	4438005010	1
	HARDWARE KIT		_
\$1-\$5 \$6/\$7	Screw, #2BTC 3x8B Screw, #2BTC 3x10B	8109230083 8109230103	5 2
S8-S19	Screw, #2BTC 3x8B	8109230083	12
S20-S29 S30-S40	Screw, #1WPTC 3x12Y Screw, #2BTC 3x8B	8159130121 8109230083	10 11
S41-S43	Screw, #1WPT 3x10B	8119130103	1
S44	Screw, #2BTC 3x8B	8109230083	1
S45 S46	Screw, Ground Screw, #1WPT 3x10B	8155000710 8119130103	1
S47	Screw, Ground	8155000710	1
S48 S49-S52	Screw, #2BTC 3x8B Screw, WSAM 4x8B	8109230083 8159440083	1 4
S53/S54	Screw, #2BTC 3x8B	8109230083	2
CP101	MISCELLANEOUS	435206122042	1
CP102	Lead Ass'y, 6P, 120mm, Mecha to Main B'D Lead Ass'y, 8P 200mm, Mecha to Main B'D Ass'y Wire, Shield, 8P 200mm, Mecha to Main B'D	4358508202	1
CP103 CP109	Ass'y Wire, Shield, 8P 200mm, Mecha to Main B'D Cable FPC, 16P, 120mm, Mecha to Main B'D	4358508201 4118616125	1
Trans 🗥	Power Transformer, 120 V, 60 Hz	2828100647	1
Label1 Label2	Label, DHHS Label, Class1	9057069130 9057067300	1
Labelz	*		•
1	MECHANICAL ASSEMBLY Body Mecha	5728001210 6220600210	1
2	Tray	6020800110	1
3	Roulette	7121400410	1
5	Clamp Chuck	6022604310 7143104610	i
6	Slider Right	7143202410	1
7 B	Slider Left Lever Chuck	7143202510 7143104510	1 1
9	Gear Loading	7103002110	1
10 11	Gear Stopper Gear Pulley	7103002210 7103002310	1 2
12	Gear Cam	7103002410	1
13 14	Gear Skip	7103002510 7115003510	1 1
15	Pulley Skip Worm	7105003010	i
16	Bushing Skip	7015005010	2
17 18	Roller Skip Not Used !	7115003610	5
1 9	Pulley Motor	7113001310	3
20 21	Base Magnet Not Used !	6063103010	1
22	Frame Body	6122622810	1
23 24	Bracket Skip Ass'y Not Used !	6503031710	1
25	Guide Tray Ass'y	6143001310	2
26 27	Cover magnet Magnet	6023408610 5125000910	1
28	Rubber Damping	6715024510	4
29	Belt Loading	7165002810	2 1
30 31	Belt Skip Rubber Wheel	7165002820 6715026210	5
32	Shaft Skip	7005008010	1
33 34	Not Used ! Spring Chuck	6555307610	1
35	Spring Bar	6555900810	1
36 37	Spring Damping Not Used !	6555014010	4
38	Connector, Skip Ass'y 2P	5798100310	1

Def No	D1-4'	##F. TO 4.44	
Ref. No.	Description	Mfr. Part No.	
39	Connector, Load Ass'y 5P	5798100309	2
40	Wire FPC 6P	5798100308	1
41-46	Not Used!		
47	Washer, Poly	8338301210	1
48	Washer, Poly	B338300810	1
49	Washer, Plain	8305003810	1
50	Screw, Mecha	B155001210	1
51	Screw, # 1 WPT 3x12Y	8159130121	1
52	Screw, # 1 WPT 3x10Y	8159130101	10
53	Screw, # 1 WPT 2.6x8Y	8159126DB1	3
54	Screw, BM 2.6x5Y	8009126051	4
55	Screw, BM 2x3Y	8009120031	2
56	Screw, Damping	8155001610	4
57	Screw, # 1 BT 2.6x8Y	8109126081	1
58	Screw, # 1 BT 3x8Y	8109130081	5
59	Screw, # 1 WPT 2.6x14Y	8159126141	1
60	Washer Plain	8305001810	1
61	Drive Unit, KSM 2101 ABM	5728001010	1
62	Motor, RF-500TB-14415	5558200310	2
63	Motor, RF-130SH-14230	5558200410	1
64	Switch, Lever, SSCF-21004A	4638003410	2
65/66	Not Used !		_

- This parts list based on American version is for European version.
 Each Initial in the Remark is denoted as follows.
 C: Changed, D: Deleted, A: Added

Ref. No.	Description	Mfr. Part No. Q	t Remark
26 27 <u>/</u>	CABINET & CHASSIS Chassis Back, SECC, Black Cord AC Power	046102044051 4308000430	1 C
Trans 🗥	MISCELLANEOUS Power Transformer, 230 V, 50 Hz	2828100657	1 C

PRODUCT SAFETY NOTICE

Each precaution in this manual should be followed during servicing. Components identified with the IEC symbol $\boldsymbol{\Delta}$ in the part list are of special significance to safety. When replacing a component identified with $\boldsymbol{\Delta}$, use only the replacement parts designated, or parts with the same ratings of resistance, wattage or voltage that are designated in the parts list in this manual. Leakage-current or resistance measurements must be made to determine that exposed parts are acceptably insulated from the supply circuit before returning the product to the customer.

ELECTRICAL PARTS LIST

PRODUCT SAFETY NOTICE: Products marked with \triangle have special characteristics important to safety.

If you replace any of these components, read carefully the product safety notice in this manual.

Don't degrade the safety of the product through improper servicing.

Resistor/Capacitor tolerance – D : $(\pm 0.5\%)$, J : $(\pm 5\%)$, K : $(\pm 10\%)$, M : $(\pm 20\%)$, Z : +80, -20%)

Ref. No.	Description				Mfr. Part No.	Q'ty	Ref. No.	Description			Mfr. Part No. Q'ty
PCB1	ASSEMBLY P.C.B MAIN CAPACITORS					1000	C229	Ceramic Tubular Mylar	0.022 uF 0.033 uF	50 V K 100 V J	3519223520 1 3679333120 1
C101/C102	Electrolytic SG	100	uF	10 V M	3479310121		C230 C231	Mylar	0.047 uF	100 V J	3679473120 1
C105 C106-C108	Electrolytic SG Electrolytic SG	22 100	uF uF	50 V M	3479322071 3479310121	1 3	C232	Electrolytic SG	22 uF 0.047 uF	50 V M 100 V J	3479322071 1 3679473120 1
C110	Electrolytic SG	0.47	иF	50 V M	3479347871	1	C234	Mylar	0.047 GF	100 4 3	00/04/0120
C111 C113/C114	Mylar Floringhain SC	0.002 100	uF uF	100 V J 10 V M	3679222120 3479310121			CONNECTORS			4428525560 1
C116	Electrolytic SG Electrolytic SG	100	uF	10 V M	3479310121		CN101 CN102	Wafer, 6P Wafer, 8P			4428525580 1
C11B	Ceramic Tubular	0.022	иF	50 V J	3519223935	1	CN103	Wafer, 8P			44285255B0 1
C119-C122 C123/C124	Not Used ! Mylar	0.047	uF	100 V J	3679473120	2	CN104 CN105	Wafer, 4P Wafer, 3P			4428525540 1 4428513430 1
C125	Electrolytic SG	2200	чE	25 V M	3409322249	1	CN106	Wafer, 4P			4428513440 1
C126 C128	Electrolytic SG Electrolytic SG	1000 100	uF uF	25 V M 10 V M	3409310249 3479310121	1	CN107 CN108	Wafer, 10P Wafer, 9P			4428525600 1 4428525590 1
C129	Electrolytic SG	1000	иF	25 V M	3409310249		CN108	Wafer, 16P, FPC, Angle			4426001116 1
C131 C132	Ceramic Tubular Ceramic Tubular	0,01 0.022	uF uF	50 V J 50 V J	3519103935 3519223935		CN110	Wafer, 9P			4428513490 1 4428525550 1
C133/134	Electrolytic SG	100	uF	16 V M	3479310131	2	CN111	Wafer, 5P			4420020000 1
C136 C137	Ceramic Tubular Ceramic Tubular	220 47	pF pF	50 V J 50 V J	3519221935 3519470935		D404/D400	DIODES			2058322101 2
C138	Electrolytic SG	4.7	üΕ	50 V M	3479347971	1	D101/D102 D103	1N4148, Switching Zener, UZ 278SC			2058322101 2 2258599115 1
C140 C141	Ceramic Tubular Ceramic Tubular	1000 220	pF pF	50 V J 50 V J	3519102935 3519221935		D104	Zener, UZ 9.1BSC			2258599128 1
C142	Ceramic Tubular	0.01	uF	50 V J	3519103935	1	D105 D106/D107	1N4002, Rectifier Zener, UZ 4.3BSB			2258100135 1 2258599102 2
C143/C144	Ceramic Tubular	10	pF pF	50 V J 50 V J	3519100935		D108	Zener, UZ 5.1BSB			2258599103 1
C145 C146	Ceramic Tubular Mylar	120 0.047	uF	100 V J	3519121935 3679473120		D109/D110 D111-D114	1N4002, Rectifier 1N4148, Switching			2258100135 2 2058322101 4
C147	Ceramic Tubular	0.022	uF	50 V J	3519223935	1	D115	1N4002, Rectifier			2258100135 1
C148/C149 C150	Ceramic Tubular Electrolytic SG	100 100	pF uF	50 V J 10 V M	3519101935 3479310121	2	D116/D117 D118/D119	1N4148,Switching			2058322101 2 2258100135 2
C151	Electrolytic SG	10	uΕ	50 V M	3479310071		D120	1N4002, Rectifier Zener, UZ 5.1BSB			2258599103 1
C152 C153/C154	Mylar Ceramic Tubular	0.002 10	uF pF	100 V J 50 V J	3679152120 3519100935		D121	1N4002, Rectifier			2258100135 1
C156	Ceramic Tubular	2200	ūΕ	16 V J	3519222915	1	D122 D123-D138	1N4148,Switching 1N4148,Switching			2058322101 1 2058322101 16
C157 C158	Electrolytic SG Ceramic Tubular	100 220	uF pF	16 V M 50 V J	3479310131 3519221935		- 10-1				
C159	Ceramic Tubular	47	ρF	50 V J	3519470935	1	IC101-IC103	INTEGRATED CIRCUITS TA7293S, Moior Control	•		2168007204 3
C160 C161	Ceramic Tubular Electrolytic SG	0.01 100	uF uF	50 V J 16 V M	3519103935 3479310131	1	IC104	SM5871AP			2138099120 1
C162	Electrolytic SG	22	uF	50 V M	3479322071	i	IC105 IC106	KIA4559S/KIA75559S, Op KA9258D	р Атр		2168206103 1 2168202120 1
C163	Electrolytic SG	100	uF	10 V M	3479310121	1	IC107	CXD2507Q			2138022120 1
C164 C165	Ceramic Tubular Electrolytic SG	0.022 100	uF uF	50 V J 16 V M	3519223935 3479310131		IC108	KA7805, Regulator			2168602105 1 2168602108 1
C166	Electrolytic SG	47	uF	16 V M	3479347031	1	IC109 IC110	KA7812, Regulator KA7912, Regulator			2168602113 1
C167 C168	Electrolytic SG Ceramic Tubular	100 0.022	υF uF	16 V M 50 V J	3479310131 3519223935		IC111	KA7808, Regulator			2168602101 1 2138322197 1
C169	Çeramic Tubular	220	ρF	50 V J	3519221935	1	IC112 IC113	CXP82320-322, DWP325 CXA1782BQ	•		2138322197 1 2138022117 1
C170 C171	Ceramic Tubular Electrolytic SG	47 0.47	pF uF	50 V J 50 V M	3519470935 3479347871						
C172	Mylar	0.01	uF	100 V J	3679103120	1	Q101	TRANSISTORS MPSA56Y, PNP, Silicon			2208206113 1
C173	Ceramic Tubular	0.022	uF uF	50 V J 100 V J	3519223935 3679333120		Q102	DTC114YS			2208622106 1
C174 C175/C176	Mylar Ceramic Tubular	10	ρF	50 V J	3519100935		Q103/Q104 Q105	KTD1302B, NPN, Silicon KTA1023/BKTA965, PNP	Silicon		2208606112 2 2228106107 1
C177	Ceramic Tubular	0.01	uF uF	50 V J	3519103935		Q106	DTC114YS			2208622106 1
C178 C179	Electrolytic SG Electrolytic SG	10 Q.47	υF	50 V M	3479310071 3479347871		Q107 Q111	BKTA1266Y/KTA1015Y, I BKTC2235/KTC1027, NP			2208206105 1 2228406120 1
C180	Ceramic Tubular	120	pF uF	50 V J	3519121935		Q112	DTC114YS			2208622106 1
C181 C182	Ceramic Tubular Not Used !	0.022	ur	50 V J	3519223935	T	Q113-Q116 Q117/Q118				2208606108 4 2228106107 2
C183	Electrolytic SG	3,3	uĘ	50 V M	3479333971		Q119/Q120		, Gillcon		2208606114 2
C184 C185	Electrolytic SG Ceramic Tubular	22 0.022	uF uF	25 V M 50 V J	3479322041 3519223935		Q121/Q122	MPSA56Y, PNP, Silicon	Ċii		2208206113 2 2208206104 2
C186/C187	Ceramic Tubular	100	pΕ	50 V J	3519101935	2	Q123/Q124 Q125/Q126	KTA970/KTA1268, PNP, BKTC2235/KTC1027, NP			2228406120 2
C188 C189	Electrolytic SG Electrolytic SG	33 0.47	uF uF	16 V M 50 V M	3479333031 3479347871	1	Q127/Q128	KTA970/KTA1268, PNP,	Silicon		2208206104 2 2208206105 1
C190	Mylar	0,002	uF	100 V J	3679152120	1	Q129 Q130/Q131	BKTA1266Y/KTA1015Y, KTC2240BL/BKTC3200,			2208206105 1 2208606108 2
C191/C192 C193	Ceramic Tubular Ceramic Tubular	10 220	ρF	50 V J	3519100935 3519221935	2	Q132/Q133	KTA1023/BKTA965, PNP	, Silicon		2228106107 2
C194	Ceramic Tubular	47	ρF	50 V J	3519470935	1	Q134/Q135 Q136/Q137		NPN, PNP		2208606108 2 2208606114 2
C196 C197	Ceramic Tubular Ceramic Disc CH	0.022 33	uF pF	50 V J 50 V J	3519223935 3528330210	1	Q138	MPSA56Y, PNP, Silicon			2208206113 1
C198	Ceramic Tubular	0.022	üΕ	50 V J	3519223935	1	Q140 Q141/Q142	DTC114YS BKTC2235/KTC1027, NP	N Silicon		2208622106 1 2228406120 2
C199	Ceramic Disc CH	33	pΕ	50 V J	3528330210	1	Q143-Q146	KTA970/KTA1268, PNP,	Silicon		2208206104 4
C200 C201/C202	Electrolytic SG Electrolytic SG	100 0.47	uF uF	16 V M 50 V M	3479310131 3479347871	1 2	Q147/Q148				2208606112 2 2208222105 2
C205	Mylar	0.033	uF	100 V J	3679333120	1	Q149/Q150	DIATIATS, PRP, SHOON			2200222105 2
C206 C207	Mylar Mylar	0.047 0.01	uF uF	100 V J 100 V J	3679473120 3679103120			RESISTORS	4 1	1/5 W J	3029102970 2
C208	Mylar	0.022	uF	100 V J	3679223120	1	R101/R102 R103	Metal Film Carbon Film		1/5W J	3029102970 2 3069473970 1
C209 C210	Mylar Electrolytic SG	0.1 4.7	uF uF	100 V J 50 V M	3679104120 3479347971	1	R104	Metal Film	4.4 kahm	1/5 W J	3029472970 1
C211	Mylar	0.1	uЕ	100 V J	3679104120	1	R105-R109 R110	Carbon Film Metal Film		i 1/5 W J i 1/5 W J	3069473970 5 3029272970 1
C212 C219	Mylar Mylar	0.01 0.1	uF uF	100 V J 100 V J	3679103120 3679104120	1	R111	Metal Film	2.2 ahm	1/5 W J	3029229970 1
C220	Ceramic Tubular	0.022	uЕ	50 V K	3519223520	1	R112 R113	Carbon Film Carbon Film		i 1/5 W J i 1/5 W J	3069473970 1 3069752970 1
C221	Ceramic Tubular	0.002	uF	50 V K	3519222915	1	R116	Carbon Film	12 kohm	1/5 W J	3069123970 1
C222 C223	Electrolytic SG Mylar	100 0,1	uF uF	10 V M 100 V J	3479310121 3679104120		R117 R118	Carbon Film Metal Film		1/5 W J 1/5 W J	3069302970 1 3029229970 1
C224	Electrolytic SG	1	иF	50 V M	3479310971	1	R120	Metal Film	2.2 kohm	1/5 W J	3029222970 1
C225 C226	Ceramic Tubular Electrolytic SG	0.022 47	uF uF	50 V K 25 V M	3519223520 3479347041	1	R121/R122	Metal Film Çarbon Film		1/5W J 1/5W J	3029102970 2 3069473970 1
C227/C228	Ceramic Tubular	220	₽F	50 V K	3519221935		R123 R124	Metal Film		1/5 W J	3029102970 1

Ref. No.	Description		Mfr. Part No. Q'ty	Ref. No.	Description Mfr. Part NoQ'ty
R126	Metal Film	1 kohm 1/5W J	3029102970 1	R250	Metal Film 1 kohm 1/5 W J 3029102970 1
R127	Carbon Film Metal Film	47 kahm 1/5W J 2,2 ohm 1/5W J	3069473970 1	R251	Carbon Film 24 kohm 1/5 W J 3069243970 1
R128/R129 R130	Metal Film	2,2 ohm 1/5W J 2,7 kohm 1/5W J	3029229970 2 3029272970 1	R252 R253	Metal Film 1 kohm 1/5 W J 3029102970 1 Carbon Film 75 kohm 1/5 W J 3069753970 1
R131	Metal Film	2.2 ohm 1/5W J	3029229970 1	R254	Carbon Film 10 kohm 1/5 W J 3069103970 1
R132	Carbon Film	8.2 kohm 1/5 W J	3069822970 1	R255/R256	Metal Film 1 kohm 1/5 W J 3029102970 2
R133-R142 R143	Metal Film Metal Film	1 kohm 1/5 W J 470 ohm 1/5 W J	3029102970 10 3029471970 1	R257R25B R259	Carbon Film 10 kohm 1/5 W J 3069103970 2 Carbon Film 470 kohm 1/5 W J 3069474970 1
R144	Metal Film	1 kohm 1/5 W J	3029102970	R260	Carbon Film 6.8 kohm 1/5 W J 3069682970 1
R145	Metal Film	330 chm 1/5 W J	3029331970 1	R261	Carbon Film 20 kohm 1/5 W J 3069203970 1
R146 R147	Metal Film Carbon Film	4.7 kohm 1/5 W J 47 kohm 1/5 W J	3029472970 1 3069473970 1	R262	Metal Film 22 ohm 1/5 W J 3029220970 1 Carbon Film 18 kohm 1/5 W J 3069183970 1
R148	Metal Film	2.2 kohm 1/5 W J	3029222970 1	R263 R264	Carbon Film 18 kohm 1/5 W J 3069183970 1 Carbon Film 5.1 kohm 1/5 W J 3069512970 1
R149	Carbon Film	10 kohm 1/5 W J	3069103970 1	R265	Carbon Film 10 kohm 1/5 W J 3069103970 1
R150 R151	Carbon Film Metal Film	12 kohm 1/5 W J	3069123970 1	R266	Carbon Film 18 kohm 1/5 W J 3069183970 1
R153	Metal Film	680 ohm 1/5W J 2.2 kohm 1/5W J	3029681970 1 3029222970 1	R267 R268	Carbon Film 10 kohm 1/5 W J 3069103970 1 Carbon Film 5.1 kohm 1/5 W J 3069512970 1
R154	Carbon Film	10 kohm 1/5 W J	3069103970 1	R269	Metal Film 22 ohm 1/5 W J 3029220970 1
R155	Metal Film	680 ohm 1/5 W J	3029681970 1	R270	Carbon Film 100 kohm 1/5 W J 3069104970 1
R157 R158/R159	Metal Film Carbon Film	470 ohm 1/5W J 10 kohm 1/5W J	3029471970 1 3069103970 2	R271/R272 R273	Carbon Film 47 kohm 1/5 W J 3069473970 2 Carbon Film 100 kohm 1/5 W J 3069104970 1
R160	Metal Film	470 ohm 1/5 W J	3029471970 1	R274	Carbon Film 68 kohm 1/5 W J 3069683970 1
R161	Carbon Film	10 kohm 1/5W J	3069103970 1	R275	Carbon Film 10 kohm 1/5 W J 3069103970 1
R162 R164	Metal Film Metal Film	470 ohm 1/5W J 2.7 kohm 1/5W J	3029471970 1 3029272970 1	R276 R277-R279	Carbon Film 680 kohm 1/5 W J 3069684970 1 Carbon Film 10 kohm 1/5 W J 3069103970 3
R165	Carbon Film	3.6 kohm 1/5 W J	3069362970 1	R211-R219	Carbon Film 10 kohm 1/5 W J 3069103970 3
R166	Carbon Film	100 kohm 1/5 W J	3069104970 1		MISCELLANEOUS
R167 R168	Metal Film Carbon Film	10 ahm 1/5W J 39 ahm 1/5W J	3029100970 1 3069390970 1	W01	Wire Lug, 200mm, to Chassis 4359971020 1 Resonator, CST10.00MTW 3938131750 1
R169	Carbon Film	10 kohm 1/5 W J	3069390970 1 3069103970 1	X101 X102	Resonator, CST10.00MTW 3938131750 1 Crystal, 16.9344 Mhz 3938101500 1
R171	Metal Film	150 chm 1/5W J	3029151970 1	B1-B5	Bead Cord, 3580 2648702130 5
R172	Metal Film	75 ohm 1/5W J	3029750970 1	FL	FIP 4EM6 2328130311 1
R173 R174	Metal Film Carbon Film	10 ahm 1/5W J 39 ahm 1/5W J	3029100970 1 3069390970 1	L101 19	Inductor, 10 uH 2648610082 1 Holder, FL 6513004420 1
R175	Carbon Film	1 Mohm 1/5 W J	3069105970 1	20	Heatsink Regulator TR. 7505202410 1
R176	Carbon Film	10 kahm 1/5 W J	3069103970 1	21	Heatsink Regulator TR. 7505202410 1
R177 R178	Carbon Film Carbon Film	5.1 kahm 1/5W J 12 kahm 1/5W J	3069512970 1 3069123970 1	22	Heatsink Regulator TR. 7505206110 1
R179	Metal Film	3.3 kohm 1/5 W J	3029332970 1	SW101	Switch, Tact 4658003710 1
R180/R181	Carbon Film	12 kahm 1/5W J	3069123970 2		
R182 R183	Metal Film Carbon Film	3.3 kahm 1/5W J 8.2 kahm 1/5W J	3029332970 1 3069822970 1	PCB2	ASSEMBLY PCB POWER
R184/R185	Carbon Film	20 kohm 1/5 W J	3069203970 2	CNT301 1 F301	LV BASE 3P 4428525790 1 Fuse, SB 250 mA, 125 V 5508101221 1
R186	Metal Film	33 ohm 1/5W J	3029330970 1	CN302	Wafer, AC, 2P 4428100281 1
R187	Carbon Film	27 kohm 1/5 W J	3069273970 1		Clip Fuse, PFC5000-0202 4255001010 2
R188 R189	Metal Film Carbon Film	33 ohm 1/5W J 47 kohm 1/5W J	3029330970 1 3069473970 1		
R190	Metal Film	100 ohm 1/5 W J	3029101970 1	PCB3	ASSEMBLY PCB OUTPUT
R191	Carbon Film	18 kohm 1/5 W J	3069183970 1		CAPACITORS
R192/R193 ⁻ R194	Metal Film Carbon Film	33 ohm 1/5W J 8.2 kohm 1/5W J	3029330970 2 3069822970 1	C901	Ceramic Tubular 100 pF 50 V K 3519101935 1 Ceramic Tubular 0.022 uF 50 V K 3519223520 1
R195	Carbon Film	12 kohm 1/5 W J	3069123970 1	C902 C903	Ceramic Tubular 0.022 uF 50 V K 3519223520 1 Ceramic Tubular 220 pF 50 V K 3519221935 1
R196	Metal Film	10 chm 1/5W J	3029100970 1	C904	Ceramic Tubular 0.1 uF 50 V K 3519104935 1
R197 R198	Carbon Film Metal Film	39 ohm 1/5W J 100 ohm 1/5W J	3069390970 1 3029101970 1	C905/C906	Mylar 0.005 uF 100 V J 3679472120 2
R199	Metal Film	10 ohm 1/5 W J	3029100970 1		CONNECTORS
R200	Metal Film	150 ahm 1/5W J	3029151970 1	CP104	Lead Ass'y, 4P, 240mm, to Main B'D CN104 436204243332 1
R201 R202	Carbon Film Metal Film	39 ohm 1/5W J 75 ohm 1/5W J	3069390970 1 3029750970 1	CP105	Lead Ass'y, 3P, 280mm, to Main B'D CN105 436103283331 1
R203	Metal Film	2.7 kohm 1/5 W J	3029272970 1		Coil
R204	Carbon Film	3,6 kohm 1/6 W J	3069362970 1	L901	Matching Trans 2638710020 1
R205	Metal Film	22 ohm 1/5W J	3029220970 1		-
R206 R207	Carbon Film Metal Film	10 kohm 1/5 W J 1 kohm 1/5 W J	3069103970 1 3029102970 1	IC901	INTEGRATED CIRCUIT . LTV-817, Optocoupler 2408000136 1
R208	Metal Film	2.7 kohm 1/5W J	3029272970 1	10501	240000100 T
R209	Carbon Film	3.6 kohm 1/5W J	3069362970 1		TRANSISTOR
R210 R211	Metal Film Metal Film	10 ohm 1/5W J 150 ohm 1/5W J	3029100970 1 3029151970 1	Q901	DTA114YS, PNP, Silicon 2208222105 1
R212	Carbon Film	39 ohm 1/5W J	3069390970 1		RESISTORS
R213	Metal Film	75 ohm 1/5W J	3029750970 1	R901	Metal Film 680 ohm 1/5 W J 3029681970 1
R214 R215	Metal Film Carbon Film	10 ohm 1/5W J 39 ohm 1/5W J	3029100970 1 3069390970 1	R902	Metal Film 3.9 kohm 1/5 W J 3029392970 1 Metal Film 680 ohm 1/5 W J 3029681970 1
R216	Carbon Film	5.1 kohm 1/5 W J	3069512970 1	R903 R904	Metal Film 100 ohm 1/5 W J 3029101970 1
R217	Carbon Film	12 kohm 1/5W J	3069123970 1	R905	Carbon Film 47 kohm 1/5 W J 3069473970 1
R218/R219 R220	Metal Film Carbon Film	33 ohm 1/5 W J 39 kohm 1/5 W J	3029330970 2 3069393970 1	R906	Metal Film 68 ohm 1/5 W J 3029680970 1 Metal Film 47 ohm 1/5 W J 3029470970 1
R221/R222	Carbon Film	12 kohm 1/5 W J	3069123970 2	R907 R908	Metal Film 47 ohm 1/5 W J 3029470970 1 Metal Film 270 ohm 1/5 W J 3029271970 1
R223	Carbon Film	8.2 kohm 1/5 W J	3069822970 1		770007 1811
R224	Carbon Film	18 kohm 1/5 W J	3069183970 1		MISCELLANEOUS
R225 R226	Metal Film Carbon Film	100 ohm 1/5W J 47 kehm 1/5W J	3029101970 1 3069473970 1	23 24	Jack RCA, 1P 4438111020 1 Jack, Multi, 2P 4438007510 1
R227	Carbon Film	8.2 kohm 1/5 W J	3069822970 1	25	Jack RCA, 2P 4438111320 1
R228	Carbon Film	15 kohm 1/5W J	3069153970 1		
R229/R230 R231	Carbon Film Carbon Film	20 kohm 1/5W J 27 kohm 1/5W J	3069203970 2 3069273970 1	BCD4-35500	ASSEMBLY PCB FRONT
R232/R233	Metal Film	33 ohm 1/5W J	3029330970 2	CP107	Lead Ass'y, 10P, 200mm, to Main B'D CN107 436210203332 1
R234	Metal Film	1 kohm 1/5 W J	3029102970 1		Switch, Tact 4658003710 13
R235 R236	Carbon Film Metal Film	8.2 kohm 1/5 W J 1 kohm 1/5 W J	3069822970 1 3029102970 1		
R237	Carbon Film	12 kohm 1/5 W J	3069123970 1	PCB5	ASSEMBLY PCB RMC SENSOR
R238	Carbon Film	39 ohm 1/5W J	3069390970 1	CP108	Lead Ass'y, 9P,100mm, to Main B'D CN108 436209103332 1
R239 R240	Metal Film Metal Film	10 ohm 1/5 W J 150 ohm 1/5 W J	3029100970 1 3029151970 1	SENSOR50	1 KRM63M, Remocon Module 2408001140 1
R240 R241	Metal Film Metal Film	75 ohm 1/5 W J	3029151970 1 3029750970 1	5VV501-506	Switch, Tact 4658003710 6
R242	Carbon Film	82 kohm 1/5 W J	3069823970 1		and the second s
R243	Carbon Film Metal Film	39 ohm 1/5 W J	3069390970 1		ASSENBLY PCB HEADPHONE
R244 R245	Metal Film Carbon Film	10 ohm 1/5W J 3.6 kohm 1/5W J	3029100970 1 3069362970 1	C601 C602/C603	Ceramic Tubular 0.1 uF 50 V K 3519104935 1 Ceramic Tubular 0.001 uF 50 V K 3519102935 2
R246	Carbon Film	120 kohm 1/5 W J	3069124970 1	CP106	Lead Ass'y, 4P, 180mm, to Main B'D CN106 436104183331 1
R247	Carbon Film	1 Mohm 1/5 W J	3069105970 1	R601/R602	Metai Film 1 kohm 1/5 W J 3029102970 2
R248 R249	Metal Film Carbon Film	2.7 kohm 1/5 W J 24 kohm 1/5 W J	3029272970 1 3069243970 1	R602 W02	Metal Film 1 kohm 1/5 W J 3029102970 1 Wire Lug 160mm, to Chassis 4359971016 1
		// / /		JACK1	Jack, Phone 4438005010 1

Ref. No.	Description	Part No.	Q'ty
PCB7 CN701 CP111 R701 SW701	ASSEMBLY PCB POWER SWITCH Plug, 3P, Angle Lead Assy, 5P, 350mm, to Main B'D CN111 Metal Film 1 ohm 1/5 W J Switch, Push, Power	4428851103 36205353332 3029109970 4628058310	1
PCB8	ASSEMBLY PCB LED Plug, BOT. 3P LED, SPR-54MDW3, Green/Amber	4428861003 2308222205	
PCB9 CN601 CN602 CN603 CN103	ASSEMBLY PCB CONNECTION Connector, Wafer, 5P Connector, Wafer, 6P, FPC Connector, Wafer, 15P, FPC	4428516140 4428516140 4428606965 4428616965	1 1
PCB10 R601 R602 R603 CN603 CN604 R.SENSOR DISC SENSOR		3069151970 3069103970 3069101970 4428606969 4428526520 2408001111 240821000	0 1 0 1 0 1 5 1 0 1


- This parts list based on American version is for European version.
 Each initial in the Remark is denoted as follows.
 C: Changed, D: Deleted, A: Added

Ref. No. Description	Mfr. Part No. Q't	Remark
PCBZ ASSEMBLY PCB POWER	054002009359	
↑ F301 Fuse, T 250 V, 160 m	5508301035 1	С
CN302 Wafer, AC, 2P	4428100291 1	С


IC'S LEAD IDENTI FICATION & INTERNAL DIAGRAMS


CXA1081S: IC108 (RF AMP)

1. Package Outline



2. Block Diagram





3. Pin Description


Pin No.	Symbol		1/0	Description
1	FOK	1		Focus OK input. Used for SENS output and the servo auto sequencer.
2	MON	0	1, 0	Spindle motor on/off control output.
3	MDP	0	1, Z, 0	Spindle motor servo control.
4	MDS	0	1, Z, O	Spindle motor servo control.
5	LOCK	0	1, 0	GFS is sampled at 460 Hz; when GFS is high, this pin outputs a high signal. If GFS is low eight consecutive samples, this pin outputs low.
6	TEST	1		TEST pin. Normally GND.
7	FILO	0	Analog	Master PLL (slave=digital PLL) filter output.
8	FILI	1		Master PLL filter input.
9	PCO	0	1, Z, 0	Master PLL charge pump output.
10	V _{ss}	_	_	GND.
11	AV _{ss}	_		Analog GND.
12	CLTV	1		Master VCO control voltage input.
13	AV _{DD}		-	Analog power supply (+5 V)
14	RF	1	- 11 - 11 - 1 - 1 - 1 - 1	EFM signal input.
15	BIAS	ı		Constant current input of asymmetry circuit.
16	ASYI	1		Asymmetry comparator voltage input.
17	ASYO	0	1, 0	EFM full-swing output (low=VSS, high=VDD).
18	ASYE	.		Low: asymmetry circuit off; high: asymmetry circuit on.
19	WDCK	0	1, 0	D/A interface. Word clock f=2Fs.
20	LRCK	0	1, 0	D/A interface. LR clock f=Fs.
21	PCMD	0	1, 0	D/A interface. Serial data (two's complement, MSB first).
22 '	BCK	0	1, 0	D/A interface. Bit clock.
23	GTOP .	0	1, 0	GTOP output.
24	XUGF	0	1, 0	XUGF output.
25	XPCK	0	1, 0	XPLCK output.
26	V _{DD}	_		Power supply (+5 V).
27	GFS	0	1, 0	GFS output.
28	RFCK	0	1, 0	RFCK output.
29	C2PO	0	1, 0	C2PO output.
30	XROF	0	1, 0	XRAOF output.
31	MNT3	0	1, 0	MNT 3 output.
32	MNT1	0	1, 0	MNT 1 output.
33	MNTO	0	1, 0	MNT 0 output.
34	XTAI	ı		16.9344 MHz crystal oscillation circuit input, or 33.8688 MHz input.
35	XTAO	0	1, 0	16.9344 MHz crystal oscillation circuit output.
36	XTSL	-		Crystal selection input. Set low when the crystal is 16.9344 MHz, high when 33. 8688 MHz.
37	FSTT	0	1, 0	2/3 frequency divider output for Pins 34 and 35.
38	C4M	0	1, 0	4.2336 MHz output.

Pin No.	Symbol		1/0	Description
39	DOUT	0	1, 0	Digital_Out output.
40	ЕМРН	0	1, 0	Outputs high signal when the playback disc has emphasis, low signal when no emphasis.
41	WFCK	0	1, 0	WFCK output.
42	V _{SS}			GND.
43	SCOR	0	1, 0	Outputs high signal when either subcode sync S0 or S1 is detected.
44	SBSO	0	1, 0	Sub P to W serial output.
45	EXCK	_		SBSO readout clock input.
46	soso	0	1, 0	SubQ 80-bit serial output.
47	SQCK	1		SQSO readout clock input.
48	MUTE	1		High: mute; low: release
49	SENS	0	1, 0	SENS output to CPU.
50	XRST	_	•	System reset. Reset when low.
51	DATA	-		Serial data input from CPU.
52	XLAT	1		Latch input from CPU. Serial data is latched at the falling edge.
53	CLOK	1		Serial data transfer clock input from CPU.
54	SEIN	1		Sense input from SSP.
55	CNIN	1		Track jump count signal input.
56	DATO	0	1, 0	Serial data output to SSP.
57	XLTO	0	1, 0	Serial data latch output to SSP. Latched at the falling edge.
58	V _{DD}	-		Power supply (+5 V).
59	CLKO	0	1, 0	Serial data transfer clock output to SSP.
60	SPOA	1		Microcomputer extended interface (input A).
61	SPOB	1		Microcomputer extended interface (input B).
62	SPOC	I		Microcomputer extended interface (input C).
63	SPOD	ï		Microcomputer extended interface (input D).
64	XLON	0	1, 0	Microcomputer extended interface (output).


Notes: • PCMD is two's complement output of MSB first.

- GTOP is used to monitor the frame sync protection status.
- XUGF is the negative pulse for the frame sync derived from the EFM signal. It is the signal before sync protection.
- XPLCK is the inverse of the EFM PLL clock. The PLL is designed so that the falling edge and the EFM signal transition point coincide.
- GFS goes high when the frame sync and the insertion protection timing match.
- RFCK is derived from the crystal accuracy. This signal has a cycle of 136μ .
- C2PO represents the data error status.
- ullet XRAOF is generated when the 16K RAM exceeds the \pm 4F jitter margin.


CXA 1782BQ: IC113




- * The switch state in Block Diagram is for initial resetting.
- * Switch turns to o side for 1 and to ◆ side for 0 in Serial Data Truth Table on pages 30 and 31.
- * DFCT switch turns to o side when defect signal generates for DEFECT=E in Serial Data Truth Table.
- * TG1 switch turns to 0 side and TG2 switch is left open when TG1 and TG2 (address 1 : D3) is 1.










YM3433B-D: IC103



KIA4559S/

KA78XX:

M/OAA


KA79XX:

1

GI

TA7291S;

1



WCO ①
SHL ①

SHR (6)

16/18 🕦


Всо 🕸

-∏DLO®

∏ DRO®




1. Package Outline




KA78XX: IC111, IC108, IC109

1. Package Outline




KA79XX: ICT110


1. Package Outline




TA7291S; IC101, IC102, IC103


1. Package Outline









2. Block Diagram



2. Block Diagram



2. Block Diagram



TRANSISTOR AND DIODE LEAD IDENTIFICATION

TRANSISTOR	FRONT VIEW	BOTTOM VIEW
KTA 1268BL KTC 2240B/KTC3200BL KTC 1815Y/KTC 3198Y KTA 1015Y/KTA 1266Y 2SD 1302S KTC 2235Y/KTC1027 KTC 2236AY KTA965Y/KTA1023	ECB	ECB
MPSA 06 MPSA56	EBC	T T T T T T T T T T T T T T T T T T T
DTA 114YS/KRA107M DTC 114YS	ECB	□ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □

DIODE	PACKAGE VIEW
1N 4148 1N 4002 1N 4003	
UN XX. XBSX	— <u>5</u> ———————————————————————————————————
1	TERMINAL NAME
	B : BASE C : COLLECTOR E : EMITTER


Battery (2 55180016


PACKA


540


PACKAGE EW Polyethylene Bag 9705001520 Manual Instruction 9007018340 Battery (2EA) 5518001610 Cord RCA2P 4328200510 Commander 5408000613 Cushion (2EA) Cushion 9722029510 9722029610 Film Soft PE 971500510 **Box Carton** 0496051187106


SCHEMATIC DIAGRAM















HONE PCB3 OUTPUT







PCB5 RMC SENSOR






WIRING DIAGRAM







K	L	M	N

